

# Bill Klopsch's "Working Large" Reinforcing Guidelines

More Reinforcement Needed	Less Reinforcement Needed
Larger panel	Smaller panel
Heavier (bevels, thick glass)	Usual 1/8" glass
Greater number of pieces	Simpler panel
Only glass between inside and outside of the building	Panel remains in temperature controlled environment
Natural 'hinge' lines (long straight or nearly straight lines)	Fewer 'hinge' lines
Window gets direct sunlight	Window in north facade
Installed in high traffic area	Not possible to bump or touch the window
Panel installed with a putty-bevel (glazing compound) as sealant	Panel retained with wood moldings
Fabricated in heavy lead came	Fabricated in copper foil